TECHNICAL INSTRUCTION

Activating/deactivating trend data OP12/15/16

Description

The technical instruction describes the step by step process to activate or deactivate trend data on the OP12, OP15 and OP16

Step 1	Press <u>key</u> button

|	
Step 2	Enter Code: 08434

Step 3	The user level is displayed at the top right. Here level 4 – Service Level.

| Step 4	Press button <u>installation configuration</u>.

Step 5	Press button <u>Component view</u> of the selected components

| Step 6	Press on the feeder symbol. For Example feeder 1

Step 7	Press button Service level for the component configuration
Step 8	Press button <u>Trend</u>
Step 9	0 = trend is selected to off

Step 10	Press button to oben the button Trend I - 0

Step 11	Press I = trend is selected to on

Step 12	The green I shows trend is now activated