

# TECHNICAL INSTRUCTION

## Static Feeder Calibration - OP1S



### Description

---

The technical instruction describes the step-by step process to conduct the static balancing on the OP1S.


**Step 1** Check the displayed weight value in the OP1S and note the weight value.

**Step 2** Load the dosage with a weight or press/load it by pushing down. In this step, it is important that the weight value returns to its initial value.


**Step 3** Start the automatic step chain for the static calibration of the feeding. To do this, follow the picture instructions:

Pressing the button (left of the wrench) starts the function. If the OP1S is locked, it prompts you to enter a password.


Starting the static calibration



**Step 4** Enter the code for user **level 2**.



**Step 5**




**Step 6** Press the button with the bar scale







**Step 7** Confirm the start by pressing the green check mark



**Step 8** Now enter the weight of the test weight under the weight value



|         |                                                                                                        |                                                                                      |
|---------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Step 9  | e.g. 20KG (please enter your actual test weight here)                                                  |    |
| Step 10 | Now place the test weight on the scale.                                                                |   |
| Step 11 | <p>Now place the test weight on the scale.</p> <p>➔ The controller now makes an automatic test.</p>    |  |
| Step 12 | <p>Finally, remove the weight.</p> <p>The controller now calculates the new lever arm.</p> <p>End!</p> |  |